

Introduction to Imaging in CASA



With contributions from Amanda Kepley, Crystal Brogan,
David Wilner, Urvashi Rau, and others

Atacama Large Millimeter/submillimeter Array
Expanded Very Large Array





Goals of this talk

- Gain some intuition for interferometric imaging
- Delve into the theory underlying the imaging process.
- Tour of main deconvolution task in CASA: tclean



Interferometers discretely sample the uv-plane.




Missing short spacings

- Small uv-distance: **short baselines** (measures extended emission)
- Long uv-distance: **long baselines** (measures small scale emission)
- Orientation of baseline determines orientation in the uv-plane
- **Antennas can only physically be so close together leaving a hole in the center of the uv-plane (missing short spacings)**


The observed (AKA dirty) image is the true image convolved with the PSF.

$B(u,v)$
(sampled
visibilities)




\rightleftharpoons (Fourier Transform)


$b(x,y)$
(dirty beam or
psf)



\otimes
Convolve



$T(x,y)$
(True sky
brightness)




$TD(x,y)$
(dirty
image)




- **Fourier transform of sampled visibilities yields the true sky brightness convolved with the point spread function (“dirty beam”).**
- **You need to deconvolve the PSF from the dirty image to reconstruct the source. A commonly used way to do this is called cleaning.**

This is an iterative process where the data is gridded, deconvolved, and de-gridded.



The gridding step requires pixel and image size as well as weighting scheme.



Gridding: Pixel and Image Size

- pixel size: satisfy sampling theorem for longest baselines

$$\Delta l < \frac{1}{2u_{max}} \quad \Delta m < \frac{1}{2v_{max}}$$



- in practice, 5 to 8 pixels across dirty beam main lobe to aid deconvolution
- Beam size [arcsec] = 206265.0/(longest baseline in wavelengths)

–image size: natural choice often full primary beam $A(l,m)$

- For single fields:
 - 12m : FOV[arcsec] = 6300 / nu[GHz]
 - 7m: FOV[arcsec] = 10608 / nu[GHz]
 - nu[GHz] is the sky frequency.
- For mosaics:
 - You can get the imsize from the spatial tab of the OT. The parameters "p length" and "q length" to specify the dimensions of the mosaic. If you're imaging a mosaic, pad the imsize substantially to avoid artifacts.



Gridding: Visibility Weighting

- introduce weighting function $W(u,v)$
 - modifies sampling function
 - $S(u,v) \rightarrow S(u,v)W(u,v)$
 - changes $s(l,m)$, the dirty beam
- “natural” weighting
 - $W(u,v) = 1/\sigma^2$ in occupied cells, where σ^2 is the noise variance
 - maximizes point source sensitivity
 - lowest rms in image
 - generally gives more weight to short baselines, so the angular resolution is degraded



Gridding: Visibility Weighting

- “uniform” weighting
 - $W(u,v)$ inversely proportional to local density of (u,v) samples
 - weight for occupied cell = const
 - fills (u,v) plane more uniformly and dirty beam sidelobes are lower
 - gives more weight to long baselines, so angular resolution is enhanced
 - downweights some data, so point source sensitivity is degraded
 - n.b. can be trouble with sparse (u,v) coverage: cells with few samples have same weight as cells with many
 - rarely used in practice because of this.



Gridding: Visibility Weighting

- “robust” (or “Briggs”) weighting
 - variant of uniform weighting that avoids giving too much weight to cells with low natural weight
 - software implementations differ

- e.g.
$$W(u, v) = \frac{1}{\sqrt{1 + S_N^2/S_{thresh}^2}}$$



S_N is cell natural weight

S_{thresh} is a threshold

high threshold → natural weight

low threshold → uniform weight

- *an adjustable parameter allows for continuous variation between maximum point source sensitivity and resolution*
- **Use of robust < 0.0 not recommended.**






Natural




Uniform

Robust=0

Beam



CLEAN
image





Gridding: Visibility Weighting

- `uvtaper`
 - apodize (u,v) sampling by a Gaussian
$$W(u, v) = \exp\left(-\frac{(u^2 + v^2)}{t^2}\right)$$

t = adjustable tapering parameter

 - like convolving image by a Gaussian
 - gives more weight to short baselines, degrades angular resolution
 - downweights data at long baselines, so point source sensitivity degraded
 - may improve sensitivity to extended structure sampled by short baselines
 - Not a panacea




The weighting you choose depends on your science goals.

- Good first try is robust=0.5. It's a nice balance between resolution and noise.
- Detection experiment or weak extended source: try **natural** (maybe even with a taper)
- Finer detail of strong sources: try **robust**

	Robust/Uniform	Natural	Taper
resolution	higher	medium	lower
sidelobes	lower	higher	depends
point source sensitivity	lower	maximum	lower
extended source sensitivity	lower	medium	higher



Deconvolution requires specifying how you want to create and subtract the model.




“Clean” is the most common deconvolution algorithm.

Sky Model : List of delta-functions

- (1) Construct the observed (dirty) image and PSF
- (2) Search for the location of peak amplitude.
- (3) Add a delta-function of this peak/location to the model
- (4) Subtract the contribution of this component from the dirty image - a scaled/shifted copy of the PSF

Repeat steps (2), (3), (4) until a stopping criterion is reached.

- (5) Restore : Smooth the model with a 'clean beam' and add residuals




Choices: what and how much PSF to subtract and when to stop


Adapted from slide by Urvashi Rau

clean example

$T^D(l,m)$




0 clean components




initialize

residual map




clean example


$T^D(l,m)$



30 clean components




residual map




clean example


$T^D(l,m)$



100 clean components




residual map




clean example


$T^D(l,m)$



300 clean components




residual map




clean example


$T^D(l,m)$



583 clean components




residual map




*threshold
reached*

clean example

$$T^D(l,m)$$



restored image




final image depends on

imaging parameters (pixel size, visibility weighting scheme, gridding) and deconvolution (algorithm, iterations, masks, stopping criteria)

ellipse = clean beam fwhm

How do we do all this in practice?



The main imaging task in CASA is tclean

- Tclean is a refactored version of the original clean task
 - *The original clean task is deprecated and SHOULD NOT BE USED.*
 - Tclean task
 - takes the calibrated visibilities
 - grids them on the UV-plane
 - performs the FFT to a dirty image
 - deconvolves the image
 - restores the image from clean table and residual
- Major syntax and usage changes from clean to tclean are summarized here:
https://casaguides.nrao.edu/index.php/TCLEAN_and_ALMA



TCLEAN in CASA:

There can be an intimidating number of parameters!



Start simple and make it more complicated as you need to.



```
CASA <6>: inp tclean
-----> inp(tclean)
# tclean :: Radio Interferometric Image Reconstruction
vis = '' # Name of input visibility file(s)
selectdata = True # Enable data selection parameters
  field = '' # field(s) to select
  spw = '' # spw(s)/channels to select
  timerange = '' # Range of time to select from data
  uvrange = '' # Select data within uvrange
  antenna = '' # Select data based on antenna/baseline
  scan = '' # Scan number range
  observation = '' # Observation ID range
  intent = '' # Scan Intent(s)

datacolumn = 'corrected' # Data column to image(data,corrected)
imagename = '' # Pre-name of output images
imsize = [100] # Number of pixels
cell = ['1arcsec'] # Cell size
phasecenter = '' # Phase center of the image
stokes = 'I' # Stokes Planes to make
projection = 'SIN' # Coordinate projection (SIN, HPX)
startmodel = '' # Name of starting model image
specmode = 'mfs' # Spectral definition mode
  (mfs,cube,cubedata)
reffreq = '' # Reference frequency

gridding = 'standard' # Gridding options (standard, wproject,
  widefield, mosaic, awproject)
vptable = '' # Name of Voltage Pattern table
pblimit = 0.2 # >PB gain level at which to cut off
  normalizations

deconvolver = 'hogbom' # Minor cycle algorithm (hogbom,clark,m
  ultiscale,mtmfs,mem,clarkstokes)
restoration = True # Do restoration steps (or not)
  restoringbeam = [] # Restoring beam shape to use. Default
  is the PSF main lobe
  pbcor = False # Apply PB correction on the output
  restored image

outlierfile = '' # Name of outlier-field image
  definitions

weighting = 'natural' # Weighting scheme
  (natural,uniform,briggs)
  uvtaper = [] # uv-taper on outer baselines in uv-
  plane

niter = 0 # Maximum number of iterations
usemask = 'user' # Type of mask(s) for deconvolution
  (user, pb, auto-thresh, auto-
  thresh2, or auto-multithresh)
  mask = '' # Mask (a list of image name(s) or
  # region file(s) or region string(s) )
  pbmask = 0.0 # primary beam mask

restart = True # True : Re-use existing images. False
  # : Increment imagename
savemodel = 'none' # Options to save model visibilities
  (none, virtual, modelcolumn)
calcres = True # Calculate initial residual image
calcpsf = True # Calculate PSF
parallel = False # Run major cycles in parallel

CASA <7>:
```


TCLEAN in CASA

vis = ms file (can be multiple ms'es)

imagename = whatever you want



```
CASA <6>: inp tclean
-----> inp(tclean)
# tclean :: Radio Interferometric Image Reconstruction
vis = '' # Name of input visibility file(s)
selectdata = True # Enable data selection parameters
  field = '' # field(s) to select
  spw = '' # spw(s)/channels to select
  timerange = '' # Range of time to select from data
  uvrange = '' # Select data within uvrange
  antenna = '' # Select data based on antenna/baseline
  scan = '' # Scan number range
  observation = '' # Observation ID range
  intent = '' # Scan Intent(s)
datacolumn = 'corrected' # Data column to image(data,corrected)
imagename = '' # Pre-name of output images
  imsize = [100] # Number of pixels
  cell = ['1arcsec'] # Cell size
  phasecenter = '' # Phase center of the image
  stokes = 'I' # Stokes Planes to make
  projection = 'SIN' # Coordinate projection (SIN, HPX)
  startmodel = '' # Name of starting model image
  specmode = 'mfs' # Spectral definition mode
  # (mfs,cube,cubedata)
  reffreq = '' # Reference frequency
gridding = 'standard' # Gridding options (standard, wproject,
  # widefield, mosaic, awproject)
  vptable = '' # Name of Voltage Pattern table
  pblimit = 0.2 # >PB gain level at which to cut off
  # normalizations
deconvolver = 'hogbom' # Minor cycle algorithm (hogbom,clark,m
  # ultiscale,mtmfs,mem,clarkstokes)
restoration = True # Do restoration steps (or not)
  restoringbeam = [] # Restoring beam shape to use. Default
  # is the PSF main lobe
  pbcor = False # Apply PB correction on the output
  # restored image
outlierfile = '' # Name of outlier-field image
  # definitions
weighting = 'natural' # Weighting scheme
  # (natural,uniform,briggs)
  uv taper = [] # uv-taper on outer baselines in uv-
  # plane
niter = 0 # Maximum number of iterations
usemask = 'user' # Type of mask(s) for deconvolution
  # (user, pb, auto-thresh, auto-
  # thresh2, or auto-multithresh)
  mask = '' # Mask (a list of image name(s) or
  # region file(s) or region string(s) )
  pbmask = 0.0 # primary beam mask
restart = True # True : Re-use existing images. False
  # : Increment imagename
savemodel = 'none' # Options to save model visibilities
  # (none, virtual, modelcolumn)
calcres = True # Calculate initial residual image
calcpsf = True # Calculate PSF
parallel = False # Run major cycles in parallel
```

TCLEAN in CASA

imsize = size of image
in pixels = typically
primary beam (i.e., FOV)

cell = size of pixels in
angular units = typically
5-8 pixels across
synthesized beam
(resolution)

See slide 7 for more
details.



```
CASA <6>: inp tclean
-----> inp(tclean)
# tclean :: Radio Interferometric Image Reconstruction
vis = '' # Name of input visibility file(s)
selectdata = True # Enable data selection parameters
  field = '' # field(s) to select
  spw = '' # spw(s)/channels to select
  timerange = '' # Range of time to select from data
  uvrange = '' # Select data within uvrange
  antenna = '' # Select data based on antenna/baseline
  scan = '' # Scan number range
  observation = '' # Observation ID range
  intent = '' # Scan Intent(s)

datacolumn = 'corrected' # Data column to image(data,corrected)
imagename = '' # Pre-name of output images
imsize = [100] # Number of pixels
cell = ['1arcsec'] # Cell size
phasecenter = '' # Phase center of the image
stokes = 'I' # Stokes Planes to make
projection = 'SIN' # Coordinate projection (SIN, HPX)
startmodel = '' # Name of starting model image
specmode = 'mfs' # Spectral definition mode
  (mfs,cube,cubedata)
reffreq = '' # Reference frequency

gridding = 'standard' # Gridding options (standard, wproject,
  widefield, mosaic, awproject)
vptable = '' # Name of Voltage Pattern table
pblimit = 0.2 # >PB gain level at which to cut off
  normalizations

deconvolver = 'hogbom' # Minor cycle algorithm (hogbom,clark,m
  ultiscale,mtmfs,mem,clarkstokes)
restoration = True # Do restoration steps (or not)
  restoringbeam = [] # Restoring beam shape to use. Default
  is the PSF main lobe
  pbcor = False # Apply PB correction on the output
  restored image

outlierfile = '' # Name of outlier-field image
  definitions
weighting = 'natural' # Weighting scheme
  (natural,uniform,briggs)
  uvtaper = [] # uv-taper on outer baselines in uv-
  plane

iter = 0 # Maximum number of iterations
usemask = 'user' # Type of mask(s) for deconvolution
  (user, pb, auto-thresh, auto-
  thresh2, or auto-multithresh)
  mask = '' # Mask (a list of image name(s) or
  # region file(s) or region string(s) )
  pbmask = 0.0 # primary beam mask

restart = True # True : Re-use existing images. False
  # : Increment imagename
savemodel = 'none' # Options to save model visibilities
  (none, virtual, modelcolumn)
calcres = True # Calculate initial residual image
calcpsf = True # Calculate PSF
parallel = False # Run major cycles in parallel

CASA <7>:
```


Key tclean parameters

The **specmode** parameter controls whether you image the continuum (mfs) or line emission (cube).

The **gridding** option is used to specify what sort of gridding you will be doing (standard, mosaic, widefield, wproject, or awproject). The first two are most common with ALMA. The rest more common with the VLA.

The **deconvolver** options gives you access to different deconvolution options (hogbom, clark, mtmfs, multiscale, clarkstokes)



```
[CASA <23>]: inp
-----> inp()
# tclean :: Radio Interferometric Image Reconstruction
vis = '' # Name of input visibility file(s)
selectdata = True # Enable data selection parameters
field = '' # field(s) to select
spw = '' # spw(s)/channels to select
timerange = '' # Range of time to select from data
uvrange = '' # Select data within uvrange
antenna = '' # Select data based on antenna/baseline
scan = '' # Scan number range
observation = '' # Observation ID range
intent = '' # Scan Intent(s)

datacolumn = 'corrected' # Data column to image(data,corrected)
imagename = '' # Pre-name of output images
imsize = [100] # Number of pixels
cell = ['1arcsec'] # Cell size
phasecenter = '' # Phase center of the image
stokes = 'I' # Stokes Planes to make
projection = 'SIN' # Coordinate projection (SIN, HPX)

startmodel = '' # Name of starting model image
specmode = 'mfs' # Spectral definition mode
# (mfs,cube,cubedata)
reffreq = '' # Reference frequency

gridding = 'standard' # Gridding options (standard, wproject,
# widefield, mosaic, awproject)
vptable = '' # Name of Voltage Pattern table
pblimit = 0.2 # >PB gain level at which to cut off
# normalizations

deconvolver = 'mtmfs' # Minor cycle algorithm (hogbom,clark,m
# ultiscale,mtmfs,mem,clarkstokes)
scales = [] # List of scale sizes (in pixels) for
# multi-scale algorithms
nterms = 2 # Number of Taylor coefficients in the
# spectral model


restoration = True # Do restoration steps (or not)
restoringbeam = [] # Restoring beam shape to use. Default
# is the PSF main lobe
pbcor = False # Apply PB correction on the output
# restored image

outlierfile = '' # Name of outlier-field image
# definitions
weighting = 'natural' # Weighting scheme
# (natural,uniform,briggs)
uvtaper = [] # uv-taper on outer baselines in uv-
# plane


niter = 0 # Maximum number of iterations
usemask = 'user' # Type of mask(s) for deconvolution
# (user, pb, auto-thresh, auto-
# thresh2, or auto-multithresh)
mask = '' # Mask (a list of image name(s) or
# region file(s) or region string(s) )
pbmask = 0.0 # primary beam mask

restart = True # True : Re-use existing images. False
# : Increment imagename
savemodel = 'none' # Options to save model visibilities
# (none, virtual, modelcolumn)
calcres = True # Calculate initial residual image
calcpsf = True # Calculate PSF
parallel = False # Run major cycles in parallel
```


Specmode options: Imaging spectral lines




Spectrum



Channel map



Position-velocity map



Fixed velocity, polarization, etc. One fixed position, polarization, etc.

Specmode options: Imaging spectral lines

specmode='cube'

- Set the dimensions of the cube
- Set Rest frequency
- Set Velocity Frame (LSRK, BARY, ...)
- Set Doppler definition (optical/radio)
- If imaging large cubes, set chanchunks=-1. Default (1) tries to put entire cube in memory, which can fail for large cubes.
- You may want to consider setting perchanweightdensity=True. This option calculates the weights per channel instead over the whole cube. This will give a flat noise spectrum at the expense of a slightly larger beam. The ALMA Cycle 7 pipeline sets perchanweightdensity=False.

tclean will calculate the Doppler corrections for you! No need to realign beforehand. If needed, **cvel2** will do it for you, e.g. when self-calibrating.



```
CASA <40>: inp tclean
-----> inp(tclean)
# tclean :: Radio Interferometric Image Reconstruction
vis = '' # Name of input visibility file(s)
selectdata = True # Enable data selection parameters
field = '' # field(s) to select
spw = '' # spw(s)/channels to select
timerange = '' # Range of time to select from data
uvrange = '' # Select data within uvrange
antenna = '' # Select data based on antenna/baseline
scan = '' # Scan number range
observation = '' # Observation ID range
intent = '' # Scan Intent(s)

datacolumn = 'corrected' # Data column to image(data,corrected)
imagename = '' # Pre-name of output images
imsize = [100] # Number of pixels
cell = ['1arcsec'] # Cell size
phasecenter = '' # Phase center of the image
stokes = 'I' # Stokes Planes to make
projection = 'SIN' # Coordinate projection (SIN, HPX)
startmodel = '' # Name of starting model image
specmode = 'cube' # Spectral definition mode
# (mfs,cube,cubedata)
nchan = 100 # Number of channels in the output
# Image
start = '100km/s' # First channel (e.g. start=3,start='1.
# 1GHz',start='15343km/s')
width = '10km/s' # Channel width (e.g. width=2,width='0.
# 1MHz',width='10km/s')
outframe = 'lsrk' # Spectral reference frame in which to
# interpret 'start' and 'width'
veltype = 'radio' # Velocity type (radio, z, ratio, beta,
# gamma, optical)
restfreq = [] # List of rest frequencies
interpolation = 'linear' # Spectral interpolation
# (nearest,linear,cubic)
chanchunks = -1 # Number of channel chunks

gridding = 'standard' # Gridding options (standard, wproject,
# widefield, mosaic, aproject)
vptable = '' # Name of Voltage Pattern table
pblimit = 0.2 # >PB gain level at which to cut off
# normalizations

deconvolver = 'hogbom' # Minor cycle algorithm (hogbom,clark,m
# ultiscale,mtmfs,mem,clarkstokes)
restoration = True # Do restoration steps (or not)
restoringbeam = [] # Restoring beam shape to use. Default
# is the PSF main lobe
pbcor = False # Apply PB correction on the output
# restored image

outlierfile = '' # Name of outlier-field image
# definitions
weighting = 'natural' # Weighting scheme
# (natural,uniform,briggs)
uvtaper = [] # uv-taper on outer baselines in uv-
# plane

filter = 0 # Maximum number of iterations
usemask = 'user' # Type of mask(s) for deconvolution
# (user, pb, auto-thresh, auto-
# thresh2, or auto-multithresh)
mask = '' # Mask (a list of image name(s) or
# region file(s) or region string(s) )
pbmask = 0.0 # primary beam mask

restart = True # True : Re-use existing images. False
# : Increment imagename
savemodel = 'none' # Options to save model visibilities
# (none, virtual, modelcolumn)
calcres = True # Calculate initial residual image
calcpsf = True # Calculate PSF
parallel = False # Run major cycles in parallel
```



Imaging spectral lines: continuum subtraction

- Generally would like to subtract continuum emission prior to imaging line data.
 - We will see how to identify line-free channels in hands-on session.
- Current best practice is to use `uvcontsub` to do the subtraction in uv plane.

```
CASA <11>: inp
-----> inp()
# uvcontsub :: Continuum fitting and subtraction in the uv plane
vis           = 'ngc3256_co.ms'   # Name of input MS. Output goes to vis + ".contsub"
field        = ''                # Select field(s) using id(s) or name(s)
fitspw       = '0:20~53;71~120'  # Spectral window;channel selection for fitting the continuum
combine      = ''                # Data axes to combine for the continuum estimation (none, or spw and/or scan)
solint       = 'int'             # Continuum fit timescale (int recommended!)
fitorder     = 0                 # Polynomial order for the fits
spw          = ''                # Spectral window selection for output
want_cont    = False             # Create vis + ".cont" to hold the continuum estimate.
async       = False              # If true the taskname must be started using uvcontsub(...)
```




Gridder options: mosaics



Mosaics are common with ALMA particularly at high frequencies

Example: SMA 1.3 mm observations: 5 pointings

- Primary beam $\sim 1'$
- Resolution $\sim 3''$



Deconvolver options: PSF sampling choices

- **deconvolver='hogbom'**
 - Subtracts shifted and scaled full PSF from residual image
 - More accurate but can be computationally expensive.
- **deconvolver='clark'**
 - Subtracts small patch of shifted and scaled PSF from residual image
 - Does the major cycle more often to compensate for the above
 - Potentially less accurate, but also less computationally expensive.
- **deconvolver='clarkstokes'**
 - Does the thing as clark, but doing each polarization product separately.



```

CASA <21>: inp
-----> inp()
# tclean :: Radio Interferometric Image Reconstruction
vis = '' # Name of input visibility file(s)
selectdata = True # Enable data selection parameters
field = '' # field(s) to select
spw = '' # spw(s)/channels to select
timerange = '' # Range of time to select from data
uvrange = '' # Select data within uvrange
antenna = '' # Select data based on antenna/baseline
scan = '' # Scan number range
observation = '' # Observation ID range
intent = '' # Scan Intent(s)

datacolumn = 'corrected' # Data column to image(data,corrected)
imagename = '' # Pre-name of output images
imsize = [100] # Number of pixels
cell = ['1arcsec'] # Cell size
phasecenter = '' # Phase center of the image
stokes = 'I' # Stokes Planes to make
projection = 'SIN' # Coordinate projection (SIN, HPX)
startmodel = '' # Name of starting model image
spwmode = 'mfs' # Spectral definition mode
(mfs,cube,cubedata)
reffreq = '' # Reference frequency

gridding = 'standard' # Gridding options (standard, wproject,
widefield, mosaic, aproject)
vptable = '' # Name of Voltage Pattern table
pblimit = 0.2 # >PB gain level at which to cut off
normalizations

deconvolver = 'hogbom' # Minor cycle algorithm (hogbom,clark,m
uliscate,mcms,mem,clarkstokes)
restoration = True # Do restoration steps (or not)
restoringbeam = [] # Restoring beam shape to use. Default
is the PSF main lobe
pbcor = False # Apply PB correction on the output
restored image

outlierfile = '' # Name of outlier-field image
definitions

weighting = 'natural' # Weighting scheme
(natural,uniform,briggs)
uvtaper = [] # uv-taper on outer baselines in uv-
plane

niter = 1 # Maximum number of iterations
gain = 0.1 # Loop gain
threshold = 0.0 # Stopping threshold
cycleniter = -1 # Maximum number of minor-cycle
iterations
cyclefactor = 1.0 # Scaling on PSF sidelobe level to
compute the minor-cycle stopping
threshold.
minpsffraction = 0.05 # PSF fraction that marks the max depth
of cleaning in the minor cycle
maxpsffraction = 0.8 # PSF fraction that marks the minimum
depth of cleaning in the minor cycle
interactive = False # Modify masks and parameters at
runtime

usemask = 'user' # Type of mask(s) for deconvolution
(user, pb, auto-thresh, auto-
thresh2, or auto-multithresh)
mask = '' # Mask (a list of image name(s) or
region file(s) or region string(s) )
pbmask = 0.0 # primary beam mask

restart = True # True : Re-use existing images. False
: Increment imagename
savemodel = 'none' # Options to save model visibilities
(none, virtual, modelcolumn)
calcres = True # Calculate initial residual image
calcpsf = True # Calculate PSF
parallel = False # Run major cycles in parallel


CASA <22>:

```


Deconvolver options: Multi-scale CLEAN

multi-scale

“classic” scale



Instead of using delta functions like hogbom or clark, one can use extended clean components to better match emission scales (multiscales, typically paraboloids)

Suggested scale parameter choice : point source, the second the size of the synthesized beam and the third 3-5 times the synthesized beam, etc.



Selecting scales that are close to the size of your source can lead to poor modeling and divergence in clean.

Deconvolver options: Multi-scale CLEAN

deconvolver='multiscale'

- **only do multiscale**
- line or narrow bandwidth continuum

deconvolver='mtmfs'

- **multiscale+multi-terms**
- wide-fractional bandwidth continuum

For both need to set scales

- Note that scales is in **pixels**
- If beam is 5 pixels across, then scales=[0,5,15] is a pretty good choice.



```

# tclean :: Radio Interferometric Image Reconstruction
vis = '' # Name of input visibility file(s)
multiscale = True # Enable data selection parameters
field = '' # field(s) to select
spw = '' # spw(s)/channels to select
timerange = '' # Range of time to select from data
uvrange = '' # Select data within uvrange
antenna = '' # Select data based on antenna/baseline
scan = '' # Scan number range
observation = '' # Observation ID range
intent = '' # Scan Intent(s)

datacolumn = 'corrected' # Data column to image(data,corrected)
imagenam = '' # Pre-name of output images
imsize = [100] # Number of pixels
cell = ['1arcsec'] # Cell size
phasecenter = '' # Phase center of the image
stokes = 'I' # Stokes Planes to make
projection = 'SIN' # Coordinate projection (SIN, HPX)
startmodel = '' # Name of starting model image
specmode = 'mfs' # Spectral definition mode
# (mfs,cube,cubedata)
reffreq = '' # Reference frequency

gridding = 'standard' # Gridding options (standard, wproject,
# widefield, mosaic, awproject)
vptable = '' # Name of Voltage Pattern table
pblimit = 0.2 # >PB gain level at which to cut off
# normalizations

deconvolver = 'multiscale' # Minor cycle algorithm (hogbom,clark,m
# ultiscale,mtmfs,mem,clarkstokes)
scales = [] # List of scale sizes (in pixels) for
# multi-scale algorithms
smallscalebias = 0.6 # A bias towards smaller scale sizes

restoringbeam = True # Do restoration steps (or not)
restoringbeam = [] # Restoring beam shape to use. Default
# is the PSF main lobe
pbcor = False # Apply PB correction on the output
# restored image

outlierfile = '' # Name of outlier-field image
# definitions
weighting = 'natural' # Weighting scheme
# (natural,uniform,briggs)
uvtaper = [] # uv-taper on outer baselines in uv-
# plane

iter = 0 # Maximum number of iterations
usemask = 'user' # Type of mask(s) for deconvolution
# (user, pb, auto-thresh, auto-
# thresh2, or auto-multithresh)
mask = '' # Mask (a list of image name(s) or
# region file(s) or region string(s) )
pbmask = 0.0 # primary beam mask

restart = True # True : Re-use existing images. False
# : Increment imagename
savemodel = 'none' # Options to save model visibilities
# (none, virtual, modelcolumn)
calcres = True # Calculate initial residual image
calcpsf = True # Calculate PSF
parallel = False # Run major cycles in parallel

CASA <51>:

```

Restoration options: Primary beam correction

pbcor=True

- Correct the output image for the primary beam (i.e., the beam pattern of the telescope)
- You want to measure things from a primary beam corrected image because it includes the response of the telescope.
- However, the noise is no longer flat across the image, which can make pretty pictures harder to make.

For multi-term mfs primary beam corrections (i.e., nterms=2) use the **widebandpbcor** task instead.

```
mpx)
:: Radio Interferometric Image Reconstruction
# Name of input visibility file(s)
# Enable data selection parameters
# field(s) to select
# spw(s)/channels to select
# Range of time to select from data
# Select data within uvrange
# Select data based on antenna/baseline
# Scan number range
# Observation ID range
# Scan Intent(s)

datacolumn = 'corrected' # Data column to image(data,corrected)
imagenam  = ''          # Pre-name of output images
imsize    = [100]      # Number of pixels
cell      = ['1arcsec'] # Cell size
phasecenter = ''      # Phase center of the image
stokes    = 'I'        # Stokes Planes to make
projection = 'SIN'     # Coordinate projection (SIN, HPX)
startmodel = ''        # Name of starting model image
specmode  = 'mfs'      # Spectral definition mode
# (mfs,cube,cubedata)
reffreq   = ''         # Reference frequency

gridding  = 'standard' # Gridding options (standard, wproject,
# widefield, mosaic, awproject)
vptable   = ''         # Name of Voltage Pattern table
pblimit   = 0.2        # >PB gain level at which to cut off
# normalizations

deconvolver = 'multiscale' # Minor cycle algorithm (hogbom,clark,m
# ultiscale,mtmfs,mem,clarkstokes)
scales     = []        # List of scale sizes (in pixels) for
# multi-scale algorithms
smallscalebias = 0.6  # A bias towards smaller scale sizes

restoration = True     # Do restoration steps (or not)
restoringbeam = []    # Restoring beam shape to use. Default
# is the PSF main lobe
pbcor       = False    # Apply PB correction on the output
# restored image

outlierfile = ''      # Name of outlier-field image
# definitions
weighting   = 'natural' # Weighting scheme
# (natural,uniform,briggs)
uvtaper     = []      # uv-taper on outer baselines in uv-
# plane

filter      = 0        # Maximum number of iterations
usemask     = 'user'   # Type of mask(s) for deconvolution
# (user, pb, auto-thresh, auto-
# thresh2, or auto-multithresh)
mask        = ''      # Mask (a list of image name(s) or
# region file(s) or region string(s) )
pbmask      = 0.0     # primary beam mask

restart     = True     # True : Re-use existing images. False
# : Increment imagename
savemodel  = 'none'   # Options to save model visibilities
# (none, virtual, modelcolumn)
calcres    = True     # Calculate initial residual image
calcpsf    = True     # Calculate PSF
parallel   = False    # Run major cycles in parallel

CASA <51>:
```


Restoration options: restoringbeam

restoringbeam='common'

- gives same beam across an entire cube.
- Recommended to run this in serial mode because of how parallel cube mode is currently implemented.
- Can clean cube in parallel mode, then restart in serial mode with restoringbeam='common' to get a common beam
 - This is what the Cycle 7 pipeline does currently.



```
mpx)
:: Radio Interferometric Image Reconstruction
# Name of input visibility file(s)
# Enable data selection parameters
# field(s) to select
# spw(s)/channels to select
# Range of time to select from data
# Select data within uvrange
# Select data based on antenna/baseline
# Scan number range
# Observation ID range
# Scan Intent(s)

datacolumn = 'corrected' # Data column to image(data,corrected)
imagenam  = ''          # Pre-name of output images
imsize    = [100]      # Number of pixels
cell      = ['1arcsec'] # Cell size
phasecenter = ''      # Phase center of the image
stokes    = 'I'       # Stokes Planes to make
projection = 'SIN'    # Coordinate projection (SIN, HPX)
startmodel = ''       # Name of starting model image
specmode  = 'mfs'     # Spectral definition mode
# (mfs,cube,cubedata)
reffreq   = ''        # Reference frequency

gridding  = 'standard' # Gridding options (standard, wproject,
# widefield, mosaic, awproject)
vptable   = ''        # Name of Voltage Pattern table
pblimit   = 0.2       # >PB gain level at which to cut off
# normalizations

deconvolver = 'multiscale' # Minor cycle algorithm (hogbom,clark,m
# ultiscale,mtmfs,mem,clarkstokes)
scales     = []       # List of scale sizes (in pixels) for
# multi-scale algorithms
smallscalebias = 0.6 # A bias towards smaller scale sizes

restoration = True    # Do restoration steps (or not)
restoringbeam = []   # Restoring beam shape to use. Default
# is the PSF main lobe
pbcor       = False  # Apply PB correction on the output
# restored image

outlierfile = ''     # Name of outlier-field image
# definitions
weighting   = 'natural' # Weighting scheme
# (natural,uniform,briggs)
uvtaper     = []     # uv-taper on outer baselines in uv-
# plane

iter        = 0      # Maximum number of iterations
usemask     = 'user' # Type of mask(s) for deconvolution
# (user, pb, auto-thresh, auto-
# thresh2, or auto-multithresh)
mask        = ''     # Mask (a list of image name(s) or
# region file(s) or region string(s) )
pbmask     = 0.0    # primary beam mask

restart     = True   # True : Re-use existing images. False
# : Increment imagename
savemodel  = 'none' # Options to save model visibilities
# (none, virtual, modelcolumn)
calcres    = True   # Calculate initial residual image
calcpsf    = True   # Calculate PSF
parallel   = False  # Run major cycles in parallel

CASA <51>:
```

Stopping parameters

- Setting **niter**>0 exposes stopping parameters
- tclean stops when it completes the maximum number of iterations or when residuals go below the threshold level, whatever comes first.
 - Set **niter** to a large, but not too large, number
 - 1000 is a decent starting point
 - The more complex your image is the larger niter you will need
 - **threshold='3mJy'**
 - Usually some multiple of your noise level (1-3 sigma)
- **Interactive=True**
 - Allows you interactive control of tclean through the viewer
 - Choice of niter and threshold can be controlled through viewer
- Other parameters largely for power users
 - Gain can be useful for cases with extended emission (although see multi-scale clean)
 - cyclefactor, cycleniter, minpsffraction, maxpsffraction all control how often the minor cycle happens.



```
(CASA <21>: inp
-----> inp()
# tclean :: Radio Interferometric Image Reconstruction
vis = '' # Name of input visibility file(s)
selectdata = True # Enable data selection parameters
field = '' # field(s) to select
spw = '' # spw(s)/channels to select
timerange = '' # Range of time to select from data
uvrange = '' # Select data within uvrange
antenna = '' # Select data based on antenna/baseline
scan = '' # Scan number range
observation = '' # Observation ID range
intent = '' # Scan Intent(s)

datacolumn = 'corrected' # Data column to image(data,corrected)
imagename = '' # Pre-name of output images
imsize = [100] # Number of pixels
cell = ['1arcsec'] # Cell size
phasecenter = '' # Phase center of the image
stokes = 'I' # Stokes Planes to make
projection = 'SIN' # Coordinate projection (SIN, HPX)
startmodel = '' # Name of starting model image
specmode = 'mfs' # Spectral definition mode
# (mfs,cube,cubedata)
reffreq = '' # Reference frequency

gridding = 'standard' # Gridding options (standard, wproject,
# widefield, mosaic, awproject)
vptable = '' # Name of Voltage Pattern table
pblimit = 0.2 # >PB gain level at which to cut off
# normalizations

deconvolver = 'hogbom' # Minor cycle algorithm (hogbom,clark,m
# ultiscale,mtmfs,mem,clarkstokes)
restoration = True # Do restoration steps (or not)
restoringbeam = [] # Restoring beam shape to use. Default
# is the PSF main lobe
pbcor = False # Apply PB correction on the output
# restored image

outlierfile = '' # Name of outlier-field image
# definitions
weighting = 'natural' # Weighting scheme
# (natural,uniform,briggs)
uvtaper = [] # uv-taper on outer baselines in uv-
# plane

niter = 1 # Maximum number of iterations
gain = 0.1 # Loop gain
threshold = 0.0 # Stopping threshold
cycleniter = -1 # Maximum number of minor-cycle
# iterations
cyclefactor = 1.0 # Scaling on PSF sidelobe level to
# compute the minor-cycle stopping
# threshold.
minpsffraction = 0.05 # PSF fraction that marks the max depth
# of cleaning in the minor cycle
maxpsffraction = 0.8 # PSF fraction that marks the minimum
# depth of cleaning in the minor cycle
interactive = False # Modify masks and parameters at
# runtime

usemask = 'user' # Type of mask(s) for deconvolution
# (user, pb, auto-thresh, auto-
# thresh2, or auto-multithresh)
mask = '' # Mask (a list of image name(s) or
# region file(s) or region string(s) )
pbmask = 0.0 # primary beam mask

restart = True # True : Re-use existing images. False
# : Increment imagename
savemodel = 'none' # Options to save model visibilities
# (none, virtual, modelcolumn)
calcres = True # Calculate initial residual image
calcpsf = True # Calculate PSF
parallel = False # Run major cycles in parallel
```


Running TCLEAN interactively

- residual image in viewer
- define a mask with defining a mouse button on shape type
- define the same mask for all channels
- or iterate through the channels with the tape deck and define separate masks

Viewer Display Panel

iterations: 100, cycles: 1, threshold: 0.1 mJy

Add, Erase

This Channel, All Channels

This Polarization, All Polarizations

Next Action: [X] [Play] [Refresh]

Right ascension, Declination

Rate: 10 /sec, Compact

Frame: Start 0, End 0, Step 1

foo.residual
+0.0404961 Pixel: 184 21 0 0
17:20:00.457 -35.00.12.341 I 0 km/s (lsrk/radio velocity)

foo.mask-contour
+0 Pixel: 184 21 0 0
17:20:00.457 -35.00.12.341 I 0 km/s (lsrk/radio velocity)
Contours: -0.6 -0.2 0.2 0.6

Running TCLEAN interactively

Stop
cleaning

Continue for
next major
cycle and
display residual

Exit interactive
mode, but continue
cleaning.

Dangerous if
control parameters
not set sensibly!!

**Using Ctrl+C
can corrupt your
ms.**

The screenshot shows the TCLEAN interactive interface. At the top is a 'Viewer Display Panel' with various tool icons. Below this is a control panel with three input fields: 'iterations' (100), 'cycles' (1), and 'threshold' (0.1 mJy). To the right of these fields are radio buttons for 'Add' and 'Erase', and options for 'This Channel', 'All Channels', 'This Polarization', and 'All Polarizations'. Further right are 'Next Action' buttons: a red 'X' (stop), a green right arrow (continue), and a green circular arrow (display residual). A blue box highlights the 'iterations', 'cycles', and 'threshold' fields, with a blue arrow pointing to a text box that says 'Change control parameters'. The main display area shows a residual map with concentric rings. Below the map are playback controls including a 'Rate' slider set to 10 /sec, a 'Frame' slider, and buttons for 'Normal' and 'Blink'. At the bottom, there are two terminal windows showing data for 'foo.residual' and 'foo.mask-contour'.

```
foo.residual
+0.0404961      Pixel: 184 21 0 0
17:20:00.457  -35.00.12.341  I  0 km/s (lsrk/radio velocity)

foo.mask-contour
+0      Pixel: 184 21 0 0
17:20:00.457  -35.00.12.341  I  0 km/s (lsrk/radio velocity)
Contours: -0.6 -0.2 0.2 0.6
```

Output of TCLEAN

Minimally:

- `my_image.pb` Primary beam model
- `my_image.image` Cleaned and restored image (Jy/clean beam)
- `my_image.mask` Clean “boxes”
- `my_image.model` Clean components (Jy/pixel)
- `my_image.psf` Dirty beam
- `my_image.residual` Residual (Jy/dirty beam)
- `my_image.sumwt` Sum of weights

Wide-field imaging, multi-term, and parallel imaging will produce additional products.

Together images can be used in subsequent tclean runs if necessary. It's good practice not to delete subsets of images.



Advanced usage: tclean can be restarted

- restart=True
 - If tclean is started again with same image name, it will try to continue deconvolution from where it left off. Make sure this is what you want. If not, give a new name or remove existing files with `rmtables('my_image.*')`
- restart=False
 - If tclean is started again with same image name, increment the image name, and start the clean process from the beginning.
- calcpsf and calcresid
 - Controls whether or not tclean calculates the psf and residual or uses what's on disk.
- Also: try **NOT** to do CTRL+C as it could corrupt your MS when it touches the visibilities in a major cycle.







Advanced usage: automasking

- **usemask='auto-multithresh'**
- Used by the ALMA Pipeline starting in Cycle 5. Also available to users as a tclean option.
- Default parameters generally good for ALMA 12m data
- General purpose algorithm so works for ALMA, VLA, ATCA, etc.
- casaguide:
https://casaguides.nrao.edu/index.php/Automasking_Guide
- Paper: [Kepley et al. 2020, PASP, 132, 1008, 02405](#)

```
-----> inp()
# tclean :: Radio Interferometric Image Reconstruction
vis = '' # Name of input visibility file(s)
selectdata = True # Enable data selection parameters
  field = '' # field(s) to select
  spw = '' # spw(s)/channels to select
  timerange = '' # Range of time to select from data
  uvrange = '' # Select data within uvrange
  antenna = '' # Select data based on antenna/baseline
  scan = '' # Scan number range
  observation = '' # Observation ID range
  intent = '' # Scan Intent(s)
datacolumn = 'corrected' # Data column to image(data,corrected)
imagename = '' # Pre-name of output images
nsize = [100] # Number of pixels
cell = ['1arcsec'] # Cell size
phasecenter = '' # Phase center of the image
stokes = 'I' # Stokes Planes to make
projection = 'SIN' # Coordinate projection (SIN, HPX)
startmodel = '' # Name of starting model image
usemodel = 'mfs' # Spectral definition mode
  (mfs, cube, cubedata)
  reffreq = '' # Reference frequency
gridding = 'mosaic' # Gridding options (standard, wproject,
  widefield, mosaic, awproject)
  normtype = 'flatnoise' # Normalization type (flatnoise,
  flatsky)
  vptable = '' # Name of Voltage Pattern table
  pblimit = 0.2 # >PB gain level at which to cut off
  normalizations # normalizations
  conjbeams = False # Use conjugate frequency for wideband
  A-terms
deconvolver = 'hogbom' # Minor cycle algorithm (hogbom,clark.m
  utillscale,mtmf,mem,clarkstokes)
restoration = True # Do restoration steps (or not)
  restoringbeam = [] # Restoring beam shape to use. Default
  is the PSF main lobe
  pbcor = False # Apply PB correction on the output
  restored image
outlierfile = '' # Name of outlier-field image
  definitions
weighting = 'natural' # Weighting scheme
  (natural,uniform,briggs)
  uv taper = [] # uv-taper on outer baselines in uv-
  plane
iter = 0 # Maximum number of iterations
usemask = 'auto-multithresh' # Type of mask(s) for deconvolution
  (user, pb, auto-thresh, auto-
  thresh2, or auto-multithresh)
  pbmask = 0.0 # primary beam mask
  sidelobethreshold = 3.0 # sidelobethreshold * the max sidelobe
  level
  noisethreshold = 5.0 # noisethreshold * rms in residual
  image
  lownoisethreshold = 1.5 # lownoisethreshold * rms in residual
  image
  negativethreshold = 0.0 # negativethreshold * rms in residual
  image
  smoothfactor = 1.0 # smoothing factor in a unit of the
  beam
  minbeamfrac = 0.3 # minimum beam fraction for pruning
  threshold to cut the smoothed mask to
  create a final mask
  growiterations = 75 # number of binary dilation iterations
restart = True # True : Re-use existing images. False
  : Increment imagename
savemodel = 'none' # Options to save model visibilities
  (none, virtual, modelcolumn)
calres = True # Calculate initial residual image
calpsf = True # Calculate PSF
parallel = False # Run major cycles in parallel
```



... some **CASA** images...



Looking ahead ...

ALMAguides

How to use these CASA Tutorials

Imaging Tutorials for CASA beginners

If you are new to CASA, start with the following tutorials. ALMA data are delivered with standard calibrations applied and they are ready for imaging. These guides cover the basic steps required for imaging and self-calibration.

- A first look at imaging in CASA This guide gives a first look at imaging and image analysis in CASA.
- A first look at self-calibration in CASA This guide demonstrates continuum self-cal.
- A first look at spectral line imaging in CASA This guide shows imaging of a spectral line.
- A first look at image analysis in CASA This guide demonstrates moment creation and basic image analysis.

Guides for reducing ALMA Science Verification data

The links below lead to overview pages for each science verification observation. The guides themselves are linked from the overview pages. These guides are a useful tools for those who would like to learn the process of calibration and imaging in detail.

The following ALMA science verification guides have been validated for CASA version 4.3. They should also work for CASA version 4.4, and they will be validated for version 4.4 soon.

- TWHydraBand7: The protoplanetary disk source TW Hya at Band 7 (0.87 mm)
- NGC3256Band3: The galaxy merger NGC 3256 at Band 3 (3 mm)
- AntennaeBand7: Mosaic of the galaxy merger NGC 4038/4039 (Antennae) at Band 7 (0.87 mm)
- IRAS16293Band9: Mosaic of the protostellar cluster IRAS16293-2422 at Band 9 (0.45 mm)
- File:BR1202_SV_Band7_Calibration_notes.pdf: Supplemental notes on the calibration of Science Verification target BR1202-0725 in CASA 3.3
- ALMA2014_LBC_SVDATA: Imaging scripts and details for the 2014 ALMA Long Baseline Campaign science verification data for Juno, Mira, HL Tau, and SDP.81.
- M100_Band3: Demonstration of combining 12m-array, 7m-array, and Total Power data for M100 using CASA 4.3.1
- 3C286_Polarization: Demonstration of the reduction of ALMA continuum polarization toward the quasar 3C286

A Guide to CASA Data Weights and How to Ensure They are Correct for Data Combination

A Guide to Processing ALMA Data for Cycle 0

This page takes you through the steps of processing Cycle 0 data from the ALMA data archive. The guide describes some helpful hints for downloading the data, and describes the process all the way through imaging and self-calibration, and image analysis.

You can also get a look at example data calibration scripts used for Cycle 0 data at the following links. These were written for CASA version 3.4.

- TDM (128 channels/spw) File:TDM.example.ms.scriptForCalibration.py
- FDM (3840 channels/spw) File:FDM.example.ms.scriptForCalibration.py
- If you need to update 3.4 scripts to 4.2, see more information [here](#)

A Tutorial for Simulating ALMA Data.

Start here to learn about simulations. The CASA 4.3 simulation examples in the above tutorial should also work for version 4.4, and they will be validated for version 4.4 soon. Jump directly to the simulations examples with the following links.

- Simulation Examples in CASA 4.3
- Examples for older versions of CASA: 4.2 4.1 4.0 3.4 3.3





For more info:
<http://www.almaobservatory.org>

The Atacama Large Millimeter/submillimeter Array (ALMA), an international astronomy facility, is a partnership of the European Organisation for Astronomical Research in the Southern Hemisphere (ESO), the U.S. National Science Foundation (NSF) and the National Institutes of Natural Sciences (NINS) of Japan in cooperation with the Republic of Chile. ALMA is funded by ESO on behalf of its Member States, by NSF in cooperation with the National Research Council of Canada (NRC) and the National Science Council of Taiwan (NSC) and by NINS in cooperation with the Academia Sinica (AS) in Taiwan and the Korea Astronomy and Space Science Institute (KASI). ALMA construction and operations are led by ESO on behalf of its Member States; by the National Radio Astronomy Observatory (NRAO), managed by Associated Universities, Inc. (AUI), on behalf of North America; and by the National Astronomical Observatory of Japan (NAOJ) on behalf of East Asia. The Joint ALMA Observatory (JAO) provides the unified leadership and management of the construction, commissioning and operation of ALMA.


Additional Slides



Interferometry Basics

Single dish: diameter gives resolution


Interferometer: diameter gives FOV and the separation gives resolution



Interferometry Basics

Single dish: diameter gives resolution


Interferometer: diameter gives FOV and the separation gives resolution



Interferometry Basics

Single dish: diameter gives resolution

Interferometer: diameter gives FOV and the separation gives resolution



Longest Distance for resolution (AKA synthesized beam)

Diameter of Single element: Field of View (AKA primary beam)

From Sky Brightness to Visibility

1. An interferometer measures the interference pattern observed by pairs of apertures
2. The interference pattern is directly related to the source brightness. In particular, for small fields of view, the complex visibility, $V(u,v)$, is the 2D Fourier transform of the brightness on the sky, $T(x,y)$



(van Cittert-Zernike theorem)

Fourier space/domain


$$V(u, v) = \iint T(x, y) e^{2\pi i(ux+vy)} dx dy$$

$$T(x, y) = \iint V(u, v) e^{-2\pi i(ux+vy)} du dv$$

Image space/domain



Some 2D Fourier Transform Pairs





narrow features transform to wide features (and vice-versa)

More 2D Fourier Transform Pairs

$T(x,y)$


elliptical
Gaussian



$\text{Amp}\{V(u,v)\}$

elliptical
Gaussian

Disk





Bessel




sharp edges result in many high spatial frequencies
(sinc function, “ringing”, Gibbs phenomenon)

ALMA observes planetary disk




You can use the plotms task in CASA to examine your visibilities.



Remember: Important structure may be missed in central hole of (u,v) coverage



Do the visibilities observed in our example discriminate between these two models of the sky brightness distribution $T(l,m)$?





- Yes... but only on baselines shorter than about $75 \text{ k}\lambda$

Missing Short Spacings: Demonstration



Sky Model



Full range of spatial scales



> 75 kλ i.e. cutting out a central hole



Courtesy D. Wilner



A note on terminology

DAT MODEL RESIDUA



-


=

The term clean is often used to indicate the entire imaging process shown here.


The term clean can also be used to refer specifically to the algorithm used for deconvolution during the minor cycle.

Here we use both versions of the term, but which version we are using should be clear from context.

DE-GRIDDING




RESIDUAL IMAGE




Minor Cycle
(Deconvolution)

MODEL IMAGE




Specmode options: Continuum Imaging


- specmode='mfs' if narrow bandwidth
- add deconvolver='mtmfs' if you have a fractional bandwidth for the aggregate continuum greater than 10% to use multi-term multi-frequency synthesis.
 - Only in ALMA Band 3 and the lower end of Band 4 can have fractional bandwidths of greater than 10% and only when both sidebands are employed.
- nterm=2 compute spectral index, 3 for curvature etc.
- tt0 average intensity, tt1 α *tt0, α images output
- takes at least nterms longer (image size dependent)



Abell 2256; Owen et al. (2014)



Narrow BW



wide BW
(better uv-coverage)

Gridder options: mosaics

gridder='mosaic'

mosweight=True

conjbeams=False

specify field for data, e.g., field='1~6'

Setting mosweight=True weights each field in the mosaic independently to avoid issues with non-uniform sensitivity for more uniform Briggs weighting values and poor uv-coverage.

ALMA recommends conjbeams=False (do not take into account the primary beam scaling with frequency).



There's a tool ("ia.linearmosaic") to stitch all pointings together entirely in the image domain after cleaning each pointing individually.

```
CASA <56>: inp
-----> inp()
# tclean :: Radio Interferometric Image Reconstruction
vis = '' # Name of input visibility file(s)
selectdata = True # Enable data selection parameters
field = '' # field(s) to select
spw = '' # spw(s)/channels to select
timerange = '' # Range of time to select from data
uvrange = '' # Select data within uvrange
antenna = '' # Select data based on antenna/baseline
scan = '' # Scan number range
observation = '' # Observation ID range
intent = '' # Scan Intent(s)

datacolumn = 'corrected' # Data column to image(data,corrected)
imagename = '' # Pre-name of output images
imsize = [100] # Number of pixels
cell = ['1arcsec'] # Cell size
phasecenter = '' # Phase center of the image
stokes = 'I' # Stokes Planes to make
projection = 'SIN' # Coordinate projection (SIN, HPX)
startmodel = '' # Name of starting model image
submode = 'mfs' # Spectral definition mode
# (mfs,cube,cubedata)
refreq = '' # Reference frequency

gridder = 'mosaic' # Gridding options (standard, wproject,
# widefield, mosaic, awproject)
normtype = 'flatnoise' # Normalization type (flatnoise,
# flatsky)
vptable = '' # Name of Voltage Pattern table
pblimit = 0.2 # >PB gain level at which to cut off
# normalizations
conjbeams = False # Use conjugate frequency for wideband
# A-terms

deconvolver = 'hogbom' # Minor cycle algorithm (hogbom,clark,m
# ultiscale,mtmfs,mem,clarkstokes)
restoration = True # Do restoration steps (or not)
restoringbeam = [] # Restoring beam shape to use. Default
# is the PSF main lobe
pbcor = False # Apply PB correction on the output
# restored image

outlierfile = '' # Name of outlier-field image
# definitions
weighting = 'natural' # Weighting scheme
# (natural,uniform,briggs)
uvtaper = [] # uv-taper on outer baselines in uv-
# plane

niter = 0 # Maximum number of iterations
usemask = 'user' # Type of mask(s) for deconvolution
# (user, pb, auto-thresh, auto-
# thresh2, or auto-multithresh)
mask = '' # Mask (a list of image name(s) or
# region file(s) or region string(s) )
pbmask = 0.0 # primary beam mask

restart = True # True : Re-use existing images. False
# : Increment imagename
savemodel = 'none' # Options to save model visibilities
# (none, virtual, modelcolumn)
calcres = True # Calculate initial residual image
calcpsf = True # Calculate PSF
parallel = False # Run major cycles in parallel
```


Advanced Usage: parallel mode

- Tclean can be run in parallel to speed up processing of images and cubes.
- The parallelization is very simple: it just splits up the work between nodes and then puts it back together at the end.
 - For cubes, this means that each chunk of channels is processed by a different node.
- This will cause statistically insignificant differences between parallel and serial processing.
- Setting this up requires a few extra steps:
 - Start casa in mpi mode: `mpicasa -n 8 casa`
 - The `-n` parameter specifies how many cores you have available. One will be used for control and `n-1` will be used for processing
 - In your `tclean` command, set `parallel=True`
 - Run your `tclean` command.
- The nodes all dump their information to a single log file.
- Cube parallelization is being refactor in CASA 6.1, which will change the above behavior.

Advanced usage: self-calibration

Make sure to set `savemodel='modelcolumn'` if self-calibrating!

- CASA measurement sets nominally have three columns (data, model, corrected) data
- `tclean` does not save model by default to save disk space.
- However if you are self-calibrating, you need the model.
- If you don't do this, `gaincal` will use the default model (point source at the phase center).
- The end result is your source appearing to move to the center of the image and possibly becoming more point-like.



- For self-cal and other imaging examples see the NA ALMA imaging script template: <https://github.com/aakepley/ALMAImagingScript>



Combining with single-dish or other interferometric maps

- If you have only images:
 - feather (or “casafeather”)
- If you have an image and an MS:
 - Can use CLEAN with the image as the model and/or feather
- If you have multiple MS plus an image:
 - Same as above, input to clean will be all the MS’es
- See [GBT Memo 300](#) for information on how combining GBT cubes with ALMA data.
- New single dish and interferometric deconvolution task coming in CASA 6.1. See [Rau, Naik, & Braun, AJ, 158, 1](#) for details of algorithm.
- Useful info from 2019 image combination workshop:
<https://github.com/teuben/dc2019>





Figure 1: uv -coverage of the ALMA 12m+7m array for the data used in this memo with the GBT (green) and ALMA TP (purple) coverages overlaid. The GBT data has significant overlap with the ALMA 12-m array uv -coverage.

From GBT Memo 300
(Hoffman and Kepley)


Combining with other data: feather

```
# feather :: Combine two images using their Fourier transforms
imagenam = '' # Name of output feathered image
highres = '' # Name of high resolution (interferometer) image
lowres = '' # Name of low resolution (single dish) image
async = False # If true the taskname must be started using feather(...)
```



We also have a graphical tool: [CASAfeather](#)

Combining with other data: model for clean



In tclean, set `startmodel='mymodel.model'`
Units for model image: Jy/pixel



Be careful to mask a large enough region!